



Revolution Paint

Installation

Mixing

- N/A

Application

- If using multiple pails, contents must be boxed together to ensure colour consistency
- Be sure to keep a wet edge with this product and plan your work to suit the product and weather conditions
- If rolling this product we recommend a 9-10mm nap synthetic roller sleeve
- For airless spray use 0.013 - 0.017 inch spray tips and adjust the flow rate and fan width to minimize water required to thin
- Can be thinned up to 5% volume with water. Only thin down the amount needed for the project and use within three days
- Do not pour thinned material back into un-thinned material

Safety Data

- Refer to RP EnviroCote SDS

Precautions and Limitations

- RP EnviroCote should not be applied in temperatures below 5°C or above 40°C
- RP EnviroCote is not suitable for areas of continual damp or areas submerged in water
- Not for use over unsealed hardwood

Transport and Storage

- Store in a cool dark place
- Keep pail sealed
- Do not stack over 3 high

Disposal

- Spilt Material must be absorbed with sand/sawdust and lifted for proper disposal
- Product must not be allowed to run into drains or open bodies of water
- Residual small amounts of leftover paint on brushes and rollers should be wiped on to an old newspaper and allowed to dry, rather than being washed down the sink. Dispose of in accordance with local council regulations

Recommendation for Application

- UNi-PRO is recommended to use for the best quality

*** Due to our policy of continuing product improvement, from time to time Revolution Paint reserves the right to modify these specifications without any further notice.

